



New Fox Part Number Codes - Watch Crystals

This is to decode the new part numbering scheme. All combinations are not available.

Example FKFSMEIHM0.032768

F	KFSM	E	I	H	M	0	.	032768
Company	Model	Tolerance	Stability	Load	Temp Code	Frequency before the decimal	Decimal or Custom Code	Frequency after the decimal
F=Fox	KFSM=FSMLF	E=20ppm	I=-0.04ppm/delta C2	B=6pF	D=-10 to +60C	000	.=.	000000
	KFSR=FSRLF			D=8pF	M=-40 to +85C		A=TBD	
	KFSX=FSXLF			H=12.5pF	I=-40 to +125C		B=TBD	
	K161=FX161			V=7pF			C=TBD	
	K122=FX122			W=9pF			D=TBD	
	K135=FX135							
	K13L=FX135L							
	K145=FX145							
	K255=FX255							
	K13A=FXA135							
	KT15=NC15LF							
	KT26=NC26LF							
	KS26=NC26SMLF							
	KM26=NC26SM-SLF							
	KT38=NC38LF							